









UNITS				ØA1
30KAV 0500 OPT119	30KAVZE 0350 OPT119	30KAVP 0500	30KAVPZE 0350	141.3
30KAV 0550 OPT119	30KAVZE 0400 OPT119	30KAVP 0550	30KAVPZE 0400	
30KAV 0600 OPT119	30KAVZE 0450 OPT 119	30KAVP 0600	30KAVPZE 0450	
30KAV 0650 OPT119	30KAVZE 0500 OPT119	30KAVP 0650	30KAVPZE 0500	
30KAV 0720	30KAVZE 0550	-	-	168.3
30KAV 0800	30KAVZE 0600	-	-	168.3
30KAVIZE 0800	-	-	-	219.1

UNITS				A	B	C	D	E
KAV	KAVZE	KAVP	KAVPZE					
0500 OPT119	0350 OPT119	0500	0350	2363	2783	1591	433	272
0550 OPT119	0400 OPT119	0550	0400	2363	2783	1591	433	272
0600 OPT119	0450 OPT119	0600	0450	2363	2783	1591	448	242
0650 OPT119	0500 OPT119	0650	0500	2363	2783	1591	448	242
0720	0550	-	-	2353	2783	1591	401	284
0800	0600	-	-	2151	2608	1766	401	284



UNITS	A	B	C	D	E
30KAVIZE 0800	2145	2608	1941	373	290

TOLERANCE ±10	30KAV 0500/0550/0600/0650 OPT 119 30KAV 0720/0800 30KAVZE 0350/0400/0450/0500 OPT 119 30KAVZE 0550/0600 30KAVP 0500/0550/0600/0650 30KAVPZE 0350/0400/0450/0500 30KAVIZE 0800		DATE 29-Sep-21	Feuille Sheet 1/4 Indice E
	00DCG000259900			




UNITS		X	Y	Z
30KAVZE	30KAV			
0350 OPT119	0500 OPT119	2841	1120	704
0400 OPT119	0550 OPT119	2842	1120	703
0450 OPT119	0600 OPT119	2844	1120	702
0500 OPT119	0650 OPT119	2846	1120	701
0550	0720	2853	1120	693
0600	0800	2842	1167	688

UNITS		X	Y	Z
30KAVPZE	30KAVP			
0350	0500	2841	1120	704
0400	0550	2842	1120	703
0450	0600	2844	1120	702
0500	0650	2846	1120	701


UNITS	X	Y	Z
30KAVIZE 0800	2886	1081	697

ELECTRICAL BOX : POWER CONNECTION


STANDARD



VUE / VIEW A




VUE / VIEW B




VUE / VIEW C


OPTION 70D



VUE / VIEW A



VUE / VIEW B



VUE / VIEW C

