










DETAIL SOUPAPE 5



DETAIL SOUPAPE 9

UNITS				A	B	C	D	E
KAV (OPT116)	KAVZE (OPT116)	KAVP (OPT116)	KAVPZE (OPT116)					
0500 OPT119	0350 OPT119	0500	0350	2783	1591	433	601	626
0550 OPT119	0400 OPT119	0550	0400	2783	1591	433	601	626
0600 OPT119	0450 OPT119	0600	0450	2783	1591	448	586	626
0650 OPT119	0500 OPT119	0650	0500	2783	1591	448	586	626
0720	0550	-	-	2783	1591	401	601	558
0800	0600	-	-	2608	1766	401	601	558




UNITS		X	Y	Z
30KAVZE	30KAV			
0350 OPT119+116	0500 OPT119+116	3122	1118	687
0400 OPT119+116	0550 OPT119+116	3175	1118	708
0450 OPT119+116	0600 OPT119+116	3156	1118	708
0500 OPT119+116	0650 OPT119+116	3158	1118	707
0550 OPT116	0720 OPT116	3198	1117	679
0600 OPT116	0800 OPT116	3153	1175	675


UNITS		X	Y	Z
30KAVPZE	30KAVP			
0350 OPT116	0500 OPT116	3122	1118	687
0400 OPT116	0550 OPT116	3175	1118	708
0450 OPT116	0600 OPT116	3156	1118	708
0500 OPT116	0650 OPT116	3158	1118	707

ELECTRICAL BOX : POWER CONNECTION


STANDARD



VUE / VIEW A




VUE / VIEW B




VUE / VIEW C


OPTION 70D



VUE / VIEW A



VUE / VIEW B



VUE / VIEW C

