

	TAILLE UNITE / UNIT SIZE											
	040R	045R	050R	055R	060R	070R	080R	090R	100R	120R	140R	160R
	Poids en fonctionnement (kg) / Operating weight (kg)											
30RB-	408	409	428	428	435	446	454	672	734	743	861	877
	Poids additionel par option / Extra weight for options											
17	6	6	6	6	2	2	2	5	5	5	5	5
23	8	8	9	9	9	9	9	15	15	18	18	18
23B	50	50	50	50	50	50	50	N-A	N-A	N-A	N-A	N-A
49	12	12	12	12	12	12	12	23	25	25	31	31
116R/V	20	20	20	20	20	20	20	20	20	25	25	25
116S/W	47	47	47	47	47	47	47	46	46	57	58	58
116T/X	16	47	47	47	47	47	47	46	57	57	58	58
116U/Y	38	38	38	38	38	38	38	36	43	43	46	46
293	17	17	17	17	17	17	17	44	44	44	44	44
307	352	352	352	352	352	352	352	418	418	418	418	418

	TAILLE UNITE / UNIT SIZE											
	040R	045R	050R	055R	060R	070R	080R	090R	100R	120R	140R	160R
	Poids net (kg) / Net weight (kg)											
30RB-	404	405	424	424	430	439	447	665	725	733	848	863
	Poids additionel par option / Extra weight for options											
17	6	6	6	6	2	2	2	5	5	5	5	5
23	8	8	9	9	9	9	9	15	15	18	18	18
23B	50	50	50	50	50	50	50	N-A	N-A	N-A	N-A	N-A
49	11	11	11	11	11	12	12	23	23	23	30	30
116R/V	20	20	20	20	20	20	20	20	20	25	25	25
116S/W	47	47	47	47	47	47	47	46	46	57	58	58
116T/X	16	47	47	47	47	47	47	46	57	57	58	58
116U/Y	38	38	38	38	38	38	38	36	43	43	46	46
293	5	5	5	5	5	5	5	9	9	9	9	9
307	144	144	144	144	144	144	144	210	210	210	210	210

		Coefficient pour répartition de charge							
Type Unité/ Unit Type	Taille / Size	Option 116	Option 307	Option 23B	P01	P02	P03	P04	
30RB-	040R	.	.	.	0.34	0.31	0.19	0.16	
	040R	X	.	.	0.31	0.30	0.20	0.18	
	040R	X	X	.	0.32	0.28	0.22	0.18	
	040R	.	.	X	0.35	0.29	0.21	0.15	
	040R	X	.	X	0.33	0.27	0.23	0.17	
	045R	.	.	.	0.23	0.25	0.25	0.27	
	045R	X	.	.	0.31	0.30	0.20	0.19	
	045R	X	X	.	0.32	0.28	0.22	0.18	
	045R	.	.	X	0.35	0.29	0.21	0.15	
	045R	.	.	X	0.33	0.27	0.23	0.17	
	050R	.	.	.	0.22	0.24	0.26	0.28	
	050R	X	.	.	0.32	0.30	0.20	0.18	
	050R	X	X	.	0.32	0.28	0.22	0.18	
	050R	.	.	X	0.35	0.30	0.20	0.15	
	050R	X	.	X	0.33	0.27	0.23	0.17	
	055R	.	.	.	0.22	0.25	0.25	0.28	
	055R	X	.	.	0.32	0.30	0.20	0.18	
	055R	X	X	.	0.32	0.28	0.22	0.18	
	055R	.	.	X	0.35	0.30	0.20	0.15	
	055R	X	.	X	0.33	0.27	0.23	0.17	
	060R	.	.	.	0.22	0.25	0.25	0.28	
	060R	X	.	.	0.32	0.30	0.20	0.18	
	060R	X	X	.	0.31	0.28	0.22	0.19	
	060R	.	.	X	0.35	0.29	0.21	0.15	
	060R	X	.	X	0.33	0.27	0.23	0.17	
	070R	.	.	.	0.22	0.25	0.25	0.28	
	070R	X	.	.	0.32	0.30	0.20	0.18	
	070R	X	X	.	0.32	0.29	0.21	0.18	
	070R	.	.	X	0.35	0.30	0.20	0.15	
	070R	X	.	X	0.33	0.27	0.23	0.17	
	080R	.	.	.	0.23	0.26	0.24	0.27	
	080R	X	.	.	0.32	0.30	0.20	0.18	
	080R	X	X	.	0.32	0.29	0.21	0.18	
	080R	.	.	X	0.35	0.30	0.20	0.15	
	080R	X	.	X	0.34	0.28	0.22	0.16	
	090R	.	.	.	0.23	0.26	0.24	0.27	
	090R	X	.	.	0.29	0.31	0.19	0.21	
	090R	X	X	.	0.29	0.31	0.19	0.21	
	100R	.	.	.	0.24	0.24	0.26	0.26	
	100R	X	.	.	0.30	0.32	0.18	0.20	
	100R	X	X	.	0.29	0.31	0.19	0.21	
	120R	.	.	.	0.24	0.25	0.25	0.26	
	120R	X	.	.	0.29	0.32	0.18	0.21	
	120R	X	X	.	0.29	0.31	0.19	0.21	
	140R	.	.	.	0.24	0.25	0.25	0.26	
	140R	X	.	.	0.32	0.32	0.18	0.18	
	140R	X	X	.	0.31	0.31	0.19	0.19	
	160R	.	.	.	0.24	0.25	0.25	0.26	
	160R	X	.	.	0.32	0.32	0.18	0.18	
	160R	X	X	.	0.31	0.31	0.19	0.19	