



OVERALL DIMENSIONS AND WATER INLET AND OUTLET CONNECTION




TOLERANCE	30RBP770R -----> 950R	Carrier	DATE	Feuille
±10	305C		24-Mar-23	Sheet
				1/7
				Indice
				A

OVERALL DIMENSIONS AND WATER INLET AND OUTLET CONNECTION WITH PUMP






TOLERANCE	30RBP770R -----> 950R	Carrier	DATE	Feuille
±10	305C		24-Mar-23	Sheet
				2/7
				Indice
				A


COG AND LIFTING INFORMATION



X (mm)	Y (mm)	Z (mm)
3688 ± 95	972 ± 45	843 ± 15





REGULATORY INFORMATION, SERVICE/ RELIEF VALVE AND SERVICE AREA



TOLERANCE	30BP770R -----> 950R	Carrier	DATE	Feuille
±10	305C		24-Mar-23	Sheet
		00DCG000468900		4/7
				Indice
				A



ELECTRICAL BOX INFORMATION



STANDARD



3 TROUS Ø11.0
HOLES

2x PE CLIENT FILETE M8
PE CUSTOMER THREADED M8



TOLERANCE	30RBP770R -----> 950R		DATE	Feuille
±10	305C		24-Mar-23	Sheet
		00DCG000468900		5/7
				Indice
				A

OPT-266



SYMBOLS DESCRIPTIONS

	ENGLISH	FRANCAIS	DEUTSCH	ESPANOL	ITALIANO
	Cooler water inlet and outlet	Entrée et sortie eau évaporateur	Kaltwasser eintritt und austritt	Entrada y salida agua al evaporador	Entrata e uscita acqua evaporatore
	NA	NA	NA	NA	NA
	Water drain	Purge eau évaporateur	Kaltwasser abfluss	Drenaje agua evaporador	Scarico acqua evaporatore
	NA	NA	NA	NA	NA
	Safety relief valve LP	Soupape de sécurité BP	Verdampfer sicherheitsventil LP	Valvula de seguridad LP	Valvola di sicurezza LP
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	Safety relief valve HP	Soupape de sécurité HP	Verdampfer sicherheitsventil HP	Verdampfer sicherheitsventil HP	Verdampfer sicherheitsventil HP
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	Services clearances required	Espace nécessaire à la maintenance	Freiraum für wartung	Espacio necesario para servicio y mantenimiento	Spazio necessario per il servizio
	NA	NA	NA	NA	NA
	Electrical box	Coffret électrique	Schaltschrang	Caja electrica	Pannello elettrico
	Main disconnect switch	Interrupteur général	Haupttrennschalter	Interruptor de desconexion principal	Sezionatore general
	NA	NA	NA	NA	NA
	Total operating weight	Poids total en fonctionnement	Betriebsgewicht	Peso en funcionamiento	Peso in funzionamento
	Inlet water	Entrée eau	Wasser eintritt	Entrada agua	Entrata acqua
	Outlet water	Sortie eau	Wasser austritt	Salida agua	Uscita acqua
	Electrical supply entry	Entrée raccordement électrique	Strom Anschlüsse	Entrada cables electricos	Entrata cavi alimentazione
	Center of gravity	Centre de gravité	Maschinenschwerpunkt	Centro de gravedad	Centro di gravita
	Handling Rigging of the unit: the sizing of the rigging or lifting elements is the responsibility of the installer	Manutention de l'unité Le dimensionnement des éléments de manutention ou de levage sont sous la responsabilité du manutentionnaire	Anheben des geräts Der installateur ist für die dimensionierung der hebeelemente verantwortlich	Sostienimento de la unidad Las dimensiones de los elementos de sostienimento o levantamiento es responsabilidad de instalador	Sollevamento dell'apparechio La responsabilita del dimensionamento degli elementi di sistema di sollevamento e di pertinenza dell'installatore