




42NC/ND UNIT SIZE – 1 LEFT

STANDARD UNIT DIMENSIONS



42NC/ND UNIT FAMILY TYPES




Family Types

Type name:




Search parameters

Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☐	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	


CABINET WITH FEET UNIT DIMENSIONS




CABINET WITHOUT FEET UNIT DIMENSIONS




LIFTING BRACKET DIMENSIONS




42NC/ND UNIT 4 PIPE – ½" GAZ




42NC/ND UNIT 2 PIPE – ½" GAZ




42NC/ND UNIT ELECTRICAL CONNECTION




ELECTRICAL CONNECTION




2 WAY VALVE WITH ON/OFF ACTUATOR 230V or 24V




4 WAY VALVE WITH ON/OFF ACTUATOR 230V or 24V





2 WAY AUTO-BALANCING VALVE WITH ACTUATOR






CONDENSATE PUMP FOR VERTICAL UNIT



CONDENSATE PUMP




CONDENSATE PUMP FOR HORIZONTAL UNIT



CONDENSATE PUMP

WITH CABINET - WITHOUT FEET





Family Types

Type name:

Search parameters

Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

WITH CABINET - WITH FEET



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☒	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	

WITH CABINET – FEET WITH GRILL




Family Types



Type name:

Search parameters

Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☒	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	





CABINET WITH GRILL – WITHOUT FEET




Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☒	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

WITHOUT CABINET – WITHOUT FEET



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	"	
2 WAY VALVE	☐	"	
4 WAY VALVE	☐	"	
COIL 42NC/ND 2PIPE	☐	"	
COIL 42NC/ND 4PIPE	☒	"	
RECTANGULAR FLANGE	☐	"	
SUPPORT BASE FOR CONCEALED UNIT	☐	"	
VERTICAL CONDENSATE PUMP	☐	"	
CABINET WITH GRILL	☐	"	
CABINET WITHOUT GRILL	☐	"	
FEET WITH GRILL	☐	"	
FEET WITHOUT GRILL	☐	"	
HORIZONTAL CONDENSATE PUMP	☐	"	
NO CABINET	☒	"	
NO FEET	☒	"	
SERVICE AREA (Default)	☐	"	

WITHOUT CABINET – WITH FEET




Family Types



Type name:

Search parameters

Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	"	
2 WAY VALVE	☐	"	
4 WAY VALVE	☐	"	
COIL 42NC/ND 2PIPE	☐	"	
COIL 42NC/ND 4PIPE	☒	"	
RECTANGULAR FLANGE	☐	"	
SUPPORT BASE FOR CONCEALED UNIT	☐	"	
VERTICAL CONDENSATE PUMP	☐	"	
CABINET WITH GRILL	☐	"	
CABINET WITHOUT GRILL	☐	"	
FEET WITH GRILL	☐	"	
FEET WITHOUT GRILL	☒	"	
HORIZONTAL CONDENSATE PUMP	☐	"	
NO CABINET	☒	"	
NO FEET	☐	"	
SERVICE AREA (Default)	☐	"	





WITHOUT CABINET – BASE SUPPORT




Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☒	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

WITHOUT FEET – RECTANGULAR FLANGE




Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☒	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

SERVICE AREA



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	"	
2 WAY VALVE	☐	"	
4 WAY VALVE	☐	"	
COIL 42NC/ND 2PIPE	☐	"	
COIL 42NC/ND 4PIPE	☒	"	
RECTANGULAR FLANGE	☐	"	
SUPPORT BASE FOR CONCEALED UNIT	☐	"	
VERTICAL CONDENSATE PUMP	☐	"	
CABINET WITH GRILL	☐	"	
CABINET WITHOUT GRILL	☐	"	
FEET WITH GRILL	☐	"	
FEET WITHOUT GRILL	☒	"	
HORIZONTAL CONDENSATE PUMP	☐	"	
NO CABINET	☒	"	
NO FEET	☐	"	
SERVICE AREA (Default)	☒	"	



A	B	C
150	210	100